



MASON INDUSTRIES, Inc.

Manufacturers of Vibration Control Products

350 Rabro Drive 2101 W. Crescent Ave., Suite D
Hauppauge, NY 11788 Anaheim, CA 92801
631/348-0282 714/535-2727
FAX 631/348-0279 FAX 714/535-5738
Info@Mason-Ind.com Info@MasonAnaheim.com

RBA, RCA, RDA, BRA, BRB, BRC & BRD NEOPRENE MOUNT INSTALLATION INSTRUCTIONS

DATE: 9-18-03

DRAWING NO. A-28108

NOTE: SUPPORTING SURFACES MUST BE FLAT AND LEVEL UNDER MOUNTS.

- 1. BLOCK UP BASE OR EQUIPMENT TO OPERATING HEIGHT AS SHOWN ON THE DRAWINGS.**
- 2. SET MOUNTS UNDER BRACKET, BASE OR EQUIPMENT HOLES AS INDICATED. MARK THE ANCHOR LOCATIONS, REMOVE MOUNTS, INSTALL ANCHORS AND RESET MOUNTS. INSERT LOCKING CAPSCREW (WITH WASHER) THRU THE HOLE AND THREAD INTO THE TAPPED HOLE IN THE CAPTIVE STEEL INSERT.**
- 3. TIGHTEN CAPSCREWS TO LOCK THE MOUNT TO THE EQUIPMENT .**

DWN: JT

CHKD:

DATE: 9-18-03