



INSTALLATION INSTRUCTIONS

For Mason SSLFH - A, B & C

1. Remove locking cap screw and place mount under the hole in the equipment base.
2. Shim mounting before securing if mount supports are badly off level.
3. Pass cap screw through hole in equipment base and screw loosely into leveling bolt.
4. Repeat this procedure in all mounting locations.
5. Keep "Upward rebound plate" from turning by restraining it with a screw driver through the adjustment port.
6. Take two full counterclockwise turns on each leveling bolt and continue even adjustment of all mounts until equipment is (a) supported on the springs, (b) is level and (c) the distance between the underside of the leveling bolt and the top side of the downstop is no more than 1/8".
 7. Take no more than 2 additional counterclockwise turns on any leveling bolt to level equipment.
 8. Tighten cap screw on each isolator to secure equipment.
9. Rotate rebound plate clockwise to lower or counterclockwise to raise such that the adjustment plate has a 1/8" clearance between the top of the plate and the underside of the all directional neoprene cushion. Prevent from winding down with Locktight or slightly damage thread.